

# Plinth - Fitting Instructions



**1** Decide where you want the Showerlay to be placed and sit the 2 parts of the Showerlay Plinth into place. Be aware of floor level at all stages.



**2** Sit the Showerlay on top of the Plinth making sure the Showerlay is not over hanging the Plinth on any sides.



**3** Mark out the position of the hole and also draw around the edges of the Showerlay with a pencil onto the Plinth.



**4** Remove the Showerlay and place the Dallmer drain upside down over the circle drawn on the Plinth. Now draw a pencil line around the Dallmer drain leaving roughly a 10mm gap.



**5** Cut both parts of the Plinth to size by cutting along the pencil lines.



**6** Cut out the hole for the drain and also space for the pipework.



**7** Lay the Plinth into position then mark the wall for the pipework. Now once again remove the Plinth and drill out the hole drawn on the wall.



**8** Now fix down the Plinth to the floor using a full bed of flexible cement based tile adhesive. Use the adhesive to help level any uneven floors.